





Gehäuseteile
Housing sections
Parties du corps
Piezas del cárter

PFAFF 1051
PFAFF 1053
PFAFF 1181
PFAFF 1183

3.01








Kopfteile
Needle head parts
Pièces de tête
Piezas de la cabeza



PFAFF 1051
PFAFF 1053
PFAFF 1181
PFAFF 1183


3.02



3.02


Kopfteile
Needle head parts
Pièces de tête
Piezas de la cabeza PFAFF 1051





Kopfteile
Needle head parts
Pièces de tête
Piezas de la cabeza PFAFF 1181



3.02



3.02


Kopfteile
Needle head parts
Pièces de tête
Piezas de la cabeza

PFAFF 1053
PFAFF 1183





91-262 320-91 (PFAFF 1183)

Anschluß siehe Seite 3-20
For connection see page 3-20
Raccord, cf. page 3-20
Para la conexión, véase la pág. 3-20




siehe Seite 3-3
see page 3-3
voir page 3-3
véase la página 3-3





Armteile PFAFF 1051
 Arm parts PFAFF 1053
 Pièces de bras PFAFF 1181
 Piezas del brazo PFAFF 1183



3.03




3.03

Armteile
Arm parts
Pièces de bras
Piezas del brazo

PFAFF 1051
PFAFF 1053
PFAFF 1181
PFAFF 1183






Armteile Arm parts

Pièces de bras
Piezas del brazo

PFAFF 1051
PFAFF 1181



3.03




3.03

Armteile
Arm parts
Pièces de bras
Piezas del brazo


PFAFF 1051
PFAFF 1053
PFAFF 1181
PFAFF 1183





Armteile PFAFF 1051
 Arm parts PFAFF 1053
 Pièces de bras PFAFF 1181
 Piezas del brazo PFAFF 1183



3.03




3.03

Armteile
Arm parts
Pièces de bras
Piezas del brazo

PFAFF 1051
PFAFF 1053
PFAFF 1181
PFAFF 1183





Armteile


Arm parts

Pièces de bras
Piezas del brazo

PFAFF 1051
PFAFF 1181



3.03


siehe Seite 3-9
see page 3-9
voir page 3-9
véase la página 3-9



3.03

Armteile	PFAFF 1051
Arm parts	PFAFF 1053
Pièces de bras	PFAFF 1181
Piezas del brazo	PFAFF 1183









Grundplattenteile
Bedplate parts
Pièces du plateau fondamental
Piezas del cárter

PFAFF 1051
PFAFF 1053
PFAFF 1181
PFAFF 1183

3.04











Grundplattenteile
Bedplate parts
Pièces du plateau fondamental
Piezas del cárter

PFAFF 1181
PFAFF 1183

3.04









Grundplattenteile
Bedplate parts
Pièces du plateau fondamental
Piezas del cárter


PFAFF 1051
PFAFF 1053
PFAFF 1181
PFAFF 1183

3.04






siehe Seite 3-5 und 3-6
see page 3-5 and 3-6
voir page 3-5 et 3-6
véase la página 3-5 y 3-6



siehe Seite 3-17
see page 3-17
voir page 3-17
véase la página 3-17

91-262 228-01


11-108 177-15 (2x)







Grundplattenteile
Bedplate parts
Pièces du plateau fondamental
Piezas del cárter


PFAFF 1051
PFAFF 1053
PFAFF 1181
PFAFF 1183

3.04










Fadenabschneid-Einrichtung (-900/24)
Thread trimmer (-900/24)
Coupe-fil (-900/24)
Cortahilos (-900/24)


PFAFF 1051
PFAFF 1181

4





Anschluß siehe Seite 4-5
For connection see page 4-5
Raccord, cf. page 4-5
Para la conexión, véase la pág. 4-5


Anschluß siehe Seite 9-2
For connection see page 9-2
Raccord, cf. page 9-2
Para la conexión, véase la pág. 9-2



Fadenabschneid-Einrichtung (-900/24)
Thread trimmer (-900/24)
Coupe-fil (-900/24)
Cortahilos (-900/24)

PFAFF 1051
PFAFF 1053
PFAFF 1181
PFAFF 1183











Fadenabschneid-Einrichtung (-900/24)
Thread trimmer (-900/24)
Coupe-fil (-900/24)
Cortahilos (-900/24)


PFAFF 1051
PFAFF 1053

4






Anschluß siehe Seite 3-20
For connection see page 3-20
Raccord, cf. page 3-20
Para la conexión véase la pág. 3-20



Anschluß siehe Seite 3-18
For connection see page 3-18
Raccord, cf. page 3-18
Para la conexión véase la pág. 3-18



95-669 358-05

91-262 209-91

12-349 901-05

91-162 597-05

91-262 184-05

12-660 390-45 (2x)

14-016 080-01 (2x)

12-610 230-45

91-262 360-05


91-262 215-91

11-108 084-15 (2x)

91-268 076-15

siehe Seite 4-5
see page 4-5
voir page 4-5
véase la pág. 4-5






Fadenabstreif-Einrichtung (-909/04)
Thread wiper (-909/04)
Racleur de fil (-909/04)
Retirahilos (-909/04)



PFAFF 1051-900/24
PFAFF 1053-900/24
PFAFF 1181-900/24
PFAFF 1183-900/24


5



Presserfuß-Automatik (-910/06)
Automatic presser foot lifter (-910/06)
Relève-pied automatique (-910/06)
Alzaprensatelas (-910/06)

PFAFF 1051-900/24
PFAFF 1053-900/24
PFAFF 1181-900/24
PFAFF 1183-900/24





Einbaumotor	PFAFF 1051-900/24
Built-in motor	PFAFF 1053-900/24
Moteur incorporé	PFAFF 1181-900/24
Motor incorporado	PFAFF 1183-900/24

9.01

